







FITTING INSTRUCTIONS

(INCLUDING SPECIFIC OPERATING PRESSURES)

CR5123HP



-  This air suspension system is designed to assist the original vehicle manufacturer's suspension – it is not meant to carry the entire rated load. We do not recommend that the coil springs be altered from the OEM suspension specification, unless an applicable commercially available suspension kit is fitted.
-  The kit is designed to suit a standard vehicle configuration – modifications to the vehicle outside the kit design parameters may adversely affect fitment and operation such as:
 - Height changes outside any noted in the kit specification.
 - Larger dampers (Shock Absorbers)
 - Wheel and tyre changes
 - Exhaust changes.
-  If your vehicle is fitted with a brake proportioning valve or stability control system, it is important to ensure this is maintained and adjusted according to the vehicle manufacturer's instructions.
-  It is recommended that only a properly qualified person installs the product and carries out maintenance. If you are not qualified and attempt to carry out such work, ensure that all safety equipment is used, and safety standards are met.
-  Ensure that you have read the full Product Manual before attempting to fit the product.
-  Ensure the Product Manual is kept with the vehicle and that any vehicle owner and/or operator is fully advised on the system and its operation before attempting to drive or operate it.



SEE OTHER WARNINGS AND IMPORTANT INFORMATION IN THE PRODUCT MANUAL


LHS = LEFT SIDE OF THE VEHICLE WHEN FACING FORWARD

STEP 1 – AIR LINE TUBING & FITTINGS - GENERAL NOTES

CUTTING

Only cut the airline tubing with a sharp blade making the cut as square as possible.

Always trim the tubing before re-inserting into the fitting.

-  If you use a sharp utility knife or razor blade great care must be taken in all cases not to cut yourself during this operation.

CONNECTING & REMOVING

To connect:


Push the freshly trimmed tubing into the fitting as far as possible.

To remove:

First release the air pressure from the system. To withdraw the tubing, push and hold the collar on the fitting away from the tube and pull out the tubing.

Hint In confined spaces an open-ended spanner can be used to evenly depress the collar and remove the airline tubing.

CUT TUBING SQUARE WITH SHARP BLADE OR TUBE CUTTER





DO NOT USE PLIERS, SIDE CUTTERS OR PIPE CUTTERS

STEP 2 – POSITION YOUR INFLATION VALVES

Select a convenient location for the air inflation valves such as the bumper or the body of the vehicle. It must be protected from road damage and be accessible for air inflation equipment.

Drill a 5/16" hole and install the air inflation valve using two 5/16" stainless steel washers as supports where required.




STEP 3 – PREPARE THE AIR LINE TUBING

The airline is supplied with split protector tube pre-fitted to shield the air line during and after installation. Decide on a suitable route for the airline from the airbag to the inflation valve location to avoid direct heat from engine, exhaust pipe, and away from sharp edges.

Uncoil the air line tubing being careful not to fold or kink it and cut to length to suit the chosen route. Once routed, the protector tube is pulled back later to prepare the protected airline.

DO NOT CONNECT OR SECURE THE AIR LINE AT THIS POINT



STEP 4 – ADD THE HIGH-PRESSURE SLEEVES

IMPORTANT: Complete initial airbag and sleeve inflation at ride height. This will allow the airbag and sleeve to mate together in the correct suspension position.

Fit the elasticated tapered end of the High-Pressure sleeve over the airbag and slide the High-Pressure sleeve over the airbag as shown. The High-Pressure sleeve is to be positioned with the tapered ends neatly over the upper and lower shoulders of the airbag as shown.

Note: Fitting airbags with high pressure sleeves will increase the material thickness to be inserted into the coil. Airbag Man recommend coil isolators be removed to help with airbag and sleeve installation.



STEP 5 – PREPARE THE VEHICLE

To fit this kit, the coil springs may need to be removed and where fitted the factory over-ride bumpers may require modification. Check the specific vehicle requirements in the below steps. Ensure this operation is carried out according to the vehicle manufacturers instructions.

STEP 5a – COLORADO 7 AND TRAILBLAZER

Remove the upper spring retainers and using a hole saw cut a 25mm hole into the centre of the retainer for the airline to pass through freely and not grab.

Ensure any rough edges are cleaned away






STEP 5b – Isuzu MU-X

Extend the rear suspension to open the coil spring winding to allow airbag insertion. Ensure all edges are smooth and spring seat area is clean.


STEP 5c – MG U9

Extend the rear suspension to open the coil spring winding to allow airbag insertion. Ensure all edges are smooth and spring seat area is clean.

<p>STEP 6 - RED PLUGS</p> <p>Use of the red plugs supplied is optional. They will enable a general reduction in airbag size which may be required to ease an airbag into a coil spring which is out of the vehicle, and they will fully flatten an airbag for easy insertion into an in-situ extended coil spring through the winding.</p> <p>USING RED PLUGS: Flatten the airbag with the airline fitted and plug the other end of the airline tubing with the red plug. The airbag should now remain flattened whilst you perform fitment into the coil spring.</p>	
<p>STEP 7 - INSTALL AIRBAG INTO THE COIL SPRING</p> <p>Insert the airbag into coil spring with the air inlet at the top.</p>	
<p>STEP 8 - ROUTE THE AIR LINE TUBING INTO THE COIL SPACE</p> <p>Route the airline tubing through the top of the coil spring seat with enough extra to protrude through the coil space for airbag connection and test.</p>	
<p>STEP 8a – Colorado 7 & Trailblazer</p> <p>Ensure that the airline is passed through the cut down override bumper.</p>	
<p>STEP 8b – Isuzu MU-X</p> <p>Route the airline through the upper spring seat.</p>	
<p>STEP 8c – MG U9</p> <p>Pass the tubing up through the top coil spring seat into the cavity and it will appear in the opening to the rear as shown; you may need a pair of long nose pliers to retrieve the airline.</p>	
<p>STEP 9 - INSTALL PROTECTOR</p> <p>Install the protector so that the countersunk hole is facing the airbag as shown.</p>	
<p>STEP 10 - CONNECT AIR LINE TUBING AND TEST CONNECTIONS</p> <p>CONNECT the airline tubing by inserting one end into the airbag air fitting, the other end into the installed inflation valve.</p> <p>Hint Flat nose pliers may be used to lightly grip the airline tubing to ensure it is fully inserted into the airbag fitting.</p> <p>INFLATE the airbag to the maximum allowed pressure (See Specific Operating Pressure Advice attached) and check for leaks at the connections using soapy water spray. We recommend a soapy water spray solution of 25% soap to 75% water.</p> <p>DEFLATE the airbag. If no leak, continue. If leak detected, remove the airline tubing, re-cut and re-test.</p> <p>CHECK airbag is not in contact with any sharp edges or is too close to exhaust heat in all load and height conditions.</p>	
<p>STEP 11 - HIGH PRESSURE SLEEVE POSITIONING</p> <p>Once the airbag and high-pressure sleeves are in the coil spring, it is recommended that you visually inspect to ensure correct positioning. You can work the high-pressure sleeve around the airbag so that it is as even as possible prior to inflating the airbag.</p>	
<p>STEP 12 - COIL SPRING RE FITMENT</p> <p>Reattach all suspension components removed earlier and return the vehicle to driving position. Ensure this operation is carried out according to the vehicle manufacturers' instructions.</p>	
<p>STEP 13 - TO FINISH</p> <p>Ensure the WARNING label is fixed in a prominent position in sight of the vehicle operator.</p> <p>Ensure the Product Information Wallet is given to the vehicle owner/operator.</p> <p>Ensure the vehicle owner/operator fully understands how to use the product.</p> <p>All fixings should be checked for tightness after the first laden run and thereafter as per the original manufacturer's recommendations.</p>	

SETTLING IN OF AIRBAGS

The airbags in this kit are smaller in diameter than the inside of the vehicles coil springs, but they can stretch out to fill the coil space. To stretch the airbags, inflate them up to 20 psi (1.4 bar) or higher, if required (but only to the maximum Specific Airbag Operating Pressure below). Leave airbags inflated for at least 2 weeks. The stretching out will allow the airbags to settle into position and provide the best performance in use.



SPECIFIC AIRBAG OPERATING PRESSURES

See operating instructions section for proper use and apply the specific pressures below:

<u>STANDARD KIT</u> <u>WITHOUT HP SLEEVES</u>	<u>HIGH PRESSURE KIT</u> <u>WITH HP SLEEVES</u>
<u>MINIMUM</u> 5 PSI (0.4 bar)	<u>MINIMUM</u> 5 PSI (0.4 bar)
<u>MAXIMUM</u> 30 PSI (2.1 bar)	<u>MAXIMUM</u> 60 PSI (4.1 bar)

Adjust and maintain pressure up to the stated maximum to level the vehicle for the load imposed and always maintain the minimum airbag pressure.

Failure to do so may result in product or vehicle damage not covered under warranty.

**IF MORE PRESSURE IS REQUIRED TO LEVEL THE VEHICLE
CALL AIRBAG MAN ON 1800 247 224 FOR FURTHER TECHNICAL ADVICE**



FREECALL 1800 247 224



- ⚠** Incorrect use of this air suspension product can result in damage to the airbag, associated parts and/or the vehicle, which is not covered under warranty.
- ⚠** Ensure the airbags are maintained at the stated ride height at all times and the maximum pressure is never exceeded.