

BT008A Fitting Guide

Vehicle: MultiFit—for Tray Back Ute
Year Model: as appropriate
Product: Auxiliary Battery Box
Product Code: BT008A

Fits up to N70zz 12 inch case battery

1. Find desired position for battery tray, place battery tray & mark to drill holes.

2. Drill 4 holes in the top of the tray, place backing plates with welded 6mm threads through tray if suitable, or use 4 x 6mm bolts, nuts & washers and tighten.



3. Sit battery into box and place battery hold down on, then tighten until battery is firmly in place.

**DRILLING REQUIRED FOR
CORRECT INSTALLATION**

Comes complete with:

5 x backing plates with welded threaded bolts & nuts
4 x 6mm bolts, nuts & washers

As all Tray Backs are different thickness, you may need to supply your own bolts as needed.