

Vehicle: Toyota Prado 150
Year Model: 2010-2013
Product: Auxiliary Battery Tray
Product Code: BT009

Fits up to N70zz 12 inch case battery

1. Battery tray fits into the front of the right hand drivers side of the vehicle under the bonnet.

3. Place the 2 x 4mm bolts in the tray in the holes towards the engine. Then place the 2 x 6mm bolts in the holes towards the guards, and tighten all bolts.



2. There is a black bracket that holds the air con pipe in position. Undo this bracket and remove. Sit battery tray into position, re-use bolt & nut from air con bracket to fix con pipe to the tray. **Make sure you DON'T undo the bolt that joins the air con pipe together, as it will release the air con gas.**

4. Sit battery in tray, fit battery hold down and tighten.

Comes complete with:
2 x 6mm bolts
2 x 4mm bolts
1 x hold down with J hooks.