

## BT013 Fitting Guide

Vehicle: Colorado / Dmax / Rodeo  
Year Model: 2007-2011  
Product: Auxiliary Battery Tray  
Product Code: BT013

Fits up to N70zz 12 inch case battery

1. Battery tray fits underneath the vehicle on the drivers side, and bolts to the chassis. It sits about 50mm lower than the chassis, but no lower than the crossmember.

3. There are two holes in the back of the box. Place 2 x 6mm long bolts through holes. One bolt sits on top of the chassis and on under the chassis rail. Place bracket onto bolts, place nuts on and tighten.



2. Sit battery tray into position. The support leg faces towards the rear of the vehicle. Align the hole in the support leg with hole in the Crossmember. Place 1 x 6mm bolt, washer & nut through hole & tighten.

4. Place the battery in the box then place the front cover on & fit 4mm nuts and tighten.

**Comes complete with:**  
3 x 6mm bolts, nuts & washers  
1 x bracket  
2 x 4mm nuts