

BT026 Fitting Guide

Vehicle: Mitsubishi Pajero
Year Model: 2008-2013
Product: Auxiliary Battery Tray
Product Code: BT026

Fits up to N70zz 12 inch case battery

1. Battery tray fits into the rear of the left hand passenger side of the vehicle under the bonnet.

3. The tray also has a support bracket that bolts to the firewall using existing bolt in firewall. Fix the bracket to the tray using 4mm bolt & nut.



2. Sit battery tray into position. The support leg to the front of the vehicle requires a 4mm bolt.

4. The two holes in the base of the tray have support legs which sit over two threaded bolts in the skirt. Fit 2 x 6mm nuts & washers onto these threads and tighten all nuts & bolts.

5. Sit battery in tray, fit battery hold down & tighten.

Comes complete with:
2 x 6mm nuts & washers
1 x 4mm bolts
1 x 4mm bolt & nut
1 x hold down with J hooks