



Part Number—DDHIL

Suits the following vehicles
Toyota Hilux KUN 2# 2005>
Toyota Prado 120 series
Toyota Prado 150 series
Toyota FJ Cruiser



Kit contents

- (A) 2 x M12 x P1.75 x 160L
- (B) 2 x 49mm x 25mm (13mm ID) Round Spacers Alloy
- (C) 4 x M12 Flat Washer
- (D) 2 x M12 nuts
- (E) 4 x M8 x P1.25 x 45L
- (F) 4 x M8 Split Washer
- (G) 4 x M8 Flat Washer
- (H) 4 x 24.5mm x 25mm (8.6mm ID) Round Spacers Alloy

Installation Guidelines

- Step 1 - Support vehicle properly on stands or hoist
- Step 2 - Remove 4 bolts from the front sump guard
- Step 3 - Remove 2 bolts from front diff mounts. Diff will not fall when these bolts are removed.
- Step 4 - Place the two large black spacers between the chassis and the factory diff mounts.
- Step 5 - Replace the factory bolts with the 2 x new 12mm bolts included with the kit (inc. nuts & washers).
Tighten to factory torque specifications.
- Step 6 - Place the four small spacers between the front sump guard & chassis, and replace original bolts (removed in step 2) with the 4 x 8mm bolts included with the kit (inc. split & flat washers). Tighten to factory torque specifications.
- Step 7 - Recheck all bolts to factory torque specifications, and lower vehicle.