

**4x4 Parts & Service
Specialists**



GRUNT

**INSTALLATION INSTRUCTIONS HOLDEN RG COLORADO
PART NUMBER: GBS-HRG**

- 1: LIFT THE BONNET AND USE THE HOLDING POST AS NORMAL.**
- 2: INSTALL THE BRACKETS ON THE BONNET AS SHOWN.
USE 2 PEOPLE, ONE TO HOLD THE BONNET, THE OTHER TO INSTALL THE BRACKET**
- 3: FIT THE BALL STUD IN THE LOCATION AS SHOWN USING THE LARGE ROUND
WASHER UNDERNEATH THE PANEL**
- 4: PUSH THE STRUT ON TO EACH END, IN THE DIRECTION AS SHOWN**
- 6: REPEAT THE PROCESS ON THE OTHER SIDE**
- 5: WHEN BOTH STRUTS ARE INSTALLED, YOU CAN REMOVE THE PEG**



**THESE INSTRUCTIONS ARE A GUIDE WE ALWAYS RECOMMEND BEING INSTALLED BY
A PROFESSIONAL & TAKE NO RESPONSIBILITY FOR DAMAGE CAUSED BY
INCORRECT FITMENT OF THE PRODUCT TO YOUR VEHICLE**