



GRUNT

INSTALLATION INSTRUCTIONS NISSAN D40 NAVARA
PART NUMBER: GBS-D40



- 1: LIFT THE BONNET AND USE THE HOLDING POST AS NORMAL.
- 2: NEXT TO THE BONNET RUBBER INSTALL THE BRACKETS MARKED "L" & "R"
- 3: INSTALL THE BRACKETS ON THE BONNET AS SHOWN.
USE 2 PEOPLE, ONE TO HOLD THE BONNET, THE OTHER TO INSTALL THE BRACKET



- 4: PUSH THE STRUT ON TO EACH END, IN THE DIRECTION AS SHOWN
- 5: WHEN BOTH STRUTS ARE INSTALLED, YOU CAN REMOVE THE PEG

THESE INSTRUCTIONS ARE A GUIDE WE ALWAYS RECOMMEND BEING INSTALLED BY A PROFESSIONAL & TAKE NO RESPONSIBILITY FOR DAMAGE CAUSED BY INCORRECT FITMENT OF THE PRODUCT TO YOUR VEHICLE