



GRUNT

INSTALLATION INSTRUCTIONS NISSAN NP300 NAVARA
PART NUMBER: GBS-NP300



1: CONNECT LEFT HAND SIDE BONNET BRACKET AS PICTURED



2: CONNECT GUARD BRACKET AS PER PICTURE MAKE SURE BALL FACE FRONT OF CAR



3: CONNECT STRUT AS PER PICTURE



4: REPEAT STEP 1, 2, 3 ON THE RIGHT HAND SIDE

**THESE INSTRUCTIONS ARE A GUIDE WE ALWAYS RECOMMEND BEING INSTALLED BY
A PROFESSIONAL & TAKE NO RESPONSIBILITY FOR DAMAGE CAUSED BY
INCORRECT FITMENT OF THE PRODUCT TO YOUR VEHICLE**