



GRUNT

INSTALLATION INSTRUCTIONS PX RANGER SLOW DOWN
PART NUMBER: GDS-FPX



Fitting to slow down strut

- 1: On the **DRIVERS SIDE** Remove the bolt nearest to the body
- 2: Place the bracket as shown and replace the bolt and tighten



3: Remove the bolt that holds the cable

4: Replace with the pre assembled strut, making sure the cable is replaced first

THESE INSTRUCTIONS ARE A GUIDE WE ALWAYS RECOMMEND BEING INSTALLED BY A PROFESSIONAL & TAKE NO RESPONSIBILITY FOR DAMAGE CAUSED BY INCORRECT FITMENT OF THE PRODUCT TO YOUR VEHICLE