

HOLDEN COLORADO SLOW DOWN STRUT
Part Number - GDS-HC



Fitting to slow down strut

- 1: On the DRIVERS SIDE** Remove the bolt nearest to the body
- 2: Place the bracket as shown** and replace the bolt and tighten



- 3: Remove the bolt that holds the cable**
 - 4: Replace with the pre assembled strut and washer provided** making sure the cable is replaced
- NOTES: DO NOT USE THE THICK FACTORY WASHER**

**THESE INSTRUCTIONS ARE A GUIDE WE ALWAYS RECOMMEND BEING INSTALLED BY
A PROFESSIONAL & TAKE NO RESPONSIBILITY FOR DAMAGE CAUSED BY
INCORRECT FITMENT OF THE PRODUCT TO YOUR VEHICLE**