



# GRUNT

INSTALLATION INSTRUCTIONS PX RANGER / MAZDA BT50 SLOW DOWN EASY UP  
PART NUMBER: GUDS-PX/BT50



1: ON THE RIGHT HAND SIDE ( DRIVERS SIDE )  
REMOVE THE BOLT NEAREST TO THE BODY  
PLACE THE BRACKET AS SHOWN, THEN REPLACE THE BOLT AND TIGHTEN.



2: REMOVE THE BOLT THAT HOLDS THE CABLE

3: REPLACE WITH THE NEW BOLT PROVIDED, MAKING SURE THE CABLE IS  
REPLACED FIRST

4: DUPLICATE PROCEEDURE FOR THE EASY LIFT STRUT  
ON THE LEFT HAND SIDE  
THEN LET DOWN THE TAILGATE AND REMOVE THE SPACER

**THESE INSTRUCTIONS ARE A GUIDE WE ALWAYS RECOMMEND BEING INSTALLED BY  
A PROFESSIONAL & TAKE NO RESPONSIBILITY FOR DAMAGE CAUSED BY  
INCORRECT FITMENT OF THE PRODUCT TO YOUR VEHICLE**