



# GRUNT

INSTALLATION INSTRUCTIONS HOLDEN COLORADO SLOW DOWN EASY UP STRUTS  
PART NUMBER: GUDS-HC



Fitting to slow down strut

- 1: On the **DRIVERS SIDE** Remove the bolt nearest to the body
- 2: Place the bracket as shown and replace the bolt and tighten



- 3: Remove the bolt that holds the cable
- 4: Replace with the pre assembled strut and washer provided making sure the cable is replaced  
NOTES: DO NOT USE THE THICK FACTORY WASHER  
Duplicate the procedure on the passenger side for the easy lift strut

5: Once the lift strut is installed let the tailgate down and remove the aluminium spacer



**THESE INSTRUCTIONS ARE A GUIDE WE ALWAYS RECOMMEND BEING INSTALLED BY A PROFESSIONAL & TAKE NO RESPONSIBILITY FOR DAMAGE CAUSED BY INCORRECT FITMENT OF THE PRODUCT TO YOUR VEHICLE**