

ROADSAFE 4WD OFFSET CASTOR CORRECTION BUSHES FITTING INSTRUCTIONS

NISSAN PATROL GQ & GU SERIES WITH COIL SPRINGS

S0499R - 2 DEGREE INCREASE FOR 50mm LIFT

This template is suitable for 50mm Lift. For lifts other than 50mm, your vertical line may be positioned different to this template, in such a case, use your vertical line and disregard this template.

Not suitable for vehicle lifts greater than 80mm. This template is suitable for 50mm Lift. For lifts other than 50mm, your vertical line may be positioned different to this template, in such a case, use your vertical line and disregard this template.

Not suitable for vehicle lifts greater than 80mm.

240mm

1. Before lifting the vehicle, mark a vertical line from the ground through the center of the OE bushing hole - and mark this on the radius arm as pictured.
2. Remove arms from vehicle.
(Removal of Track Rod and Sway Bar required)
3. Press out original bushes.
4. Compare Radius arm to this template for correct hole orientation.
5. Position front bush in line with your mark on the arm matching the template and press bush into arm.
6. Align and press rear bush into arm ensuring distance between centres is $240\text{mm} \pm 0.5\text{mm}$.
7. Ensure bushes in both arms are identical.
(Lay arms together to verify)
8. Re-install arms to vehicle, and perform wheel alignment.
(Recheck bolt tension at 500km)

ROADSAFE
4WD

← FRONT

TAP117
A4 Scale 1:1