

## INSTALLATION INSTRUCTIONS

| PART DESCRIPTION:<br>Superior Premium Mudflaps Suitable for Toyota LandCruiser 200 Series Front or Rear |         |          |                                                        |
|---------------------------------------------------------------------------------------------------------|---------|----------|--------------------------------------------------------|
| PART LISTING                                                                                            |         |          |                                                        |
| FRONT                                                                                                   |         |          |                                                        |
| ITEM#                                                                                                   | PART#   | QUANTITY | DESCRIPTION                                            |
| 1                                                                                                       | Various | 2        | Superior Premium Mudflaps Cut to suit 200 Series Front |
| 2                                                                                                       | 44963   | 10       | M6 x 16mm Dome Head Capscrew                           |
| 3                                                                                                       | 46144   | 10       | Expanding Nut -Toyota                                  |
| Rear                                                                                                    |         |          |                                                        |
| 1                                                                                                       | Various | 2        | Superior Premium Mudflaps Cut to suit 200 Series Rear  |
| 2                                                                                                       | 44963   | 12       | M6 x 16mm Dome Head Capscrew                           |
| 3                                                                                                       | 46144   | 12       | Expanding Nut -Toyota                                  |

- Before beginning installation, inspect all parts have been received and are in good condition, please refer to the list above for the kit you have ordered.
- Park the car on level ground and chock both front and rear wheels with the vehicle in park or in gear with the hand brake on. The following steps may be easier with the wheels removed.
- If the body mount needs modification to clear the tyres to do this before installing the front mud flaps.
- Remove front and/or rear factory mudflaps depending on the kit to be fitted.
- Referencing the images below, work out which mud flap goes on each corner making sure the logo is facing out towards the rear of the vehicle.
- Starting at the front of the vehicle, mark a line 50mm in from the rear outside edge of the lower front guard as per *figure 1 & 2*.
- Cut along these lines to give more clearance whilst being careful not to cut through the steel structure behind.
- With the vehicle parked on level ground, offer up the front mudflap lining up the mounting holes on the mudflap with the mounting holes on the vehicle, Check the bottom of the mud flap is no more that 300mm off the ground, if it is more than this it may need to be lowered.

## INSTALLATION INSTRUCTIONS

9. Once the height has been checked, refit the Superior mudflaps into the factory mounting locations with the included fasteners.

No cutting is needed for the rear mud flaps, please follow steps 8 & 9 for fitting the rear mud flaps.

10. *Figure 4* highlights a hole on the inner side of the mud flap. A self-tapping screw to the body will hold the inner of the mud flap back to the body mount to clear the tyre at full lock. Use of a heat gun may also help with shaping for extra clearance.

11. Once the front and rear mud flaps are fitted if there are any gaps between the body and the mud flap, a small bead of Sikaflex can be applied to make the mud flaps look more factory. Make sure to do this neatly and clean up and excesses Sikaflex. As seen in *figure 7*.

## PHOTOS FOR REFERENCE



Figure 1: Marking Out For Cutting 1

## INSTALLATION INSTRUCTIONS



Figure 1: Correctly Marked Out



Figure 2: Correctly Cut PS Guard

## INSTALLATION INSTRUCTIONS



Figure 3: Correctly Mounted Front Mud Flap DS



Figure 4: Correctly Seakaflexed

## INSTALLATION INSTRUCTIONS



Figure 6: Correctly Mounted Rear Ds Mud Flap



Figure 5: Correctly Fitted Rear Mud Flap

## INSTALLATION INSTRUCTIONS

**LH  
FRONT**

*Superior*  
**ENGINEERING.COM.AU**  
PREMIUM 4X4 ACCESSORIES

**RH  
FRONT**

*Superior*  
**ENGINEERING.COM.AU**  
PREMIUM 4X4 ACCESSORIES

**LH  
REAR**

*Superior*  
**ENGINEERING.COM.AU**  
PREMIUM 4X4 ACCESSORIES

**RH  
REAR**

*Superior*  
**ENGINEERING.COM.AU**  
PREMIUM 4X4 ACCESSORIES