

INSTALLATION INSTRUCTIONS

PART DESCRIPTION: Nissan Patrol Shock Tower Lift Kit			
PART LISTING			
ITEM#	PART#	QUANTITY	DESCRIPTION
1		6	50MM SPACERS
2		6	M12 X 90MM BOLT
3		6	M12 NYLOCK/CONELOCK

NOTES: Read and understand these installation instructions before beginning the installation process. Retain these installation instructions for future reference. It is recommended that this item is to be installed by a qualified person.

WARNING
For sufficient clearance of the shock tower, once the lift is installed, it will be necessary to cut out the inner guard or fit a body lift.

CAUTION
Please ensure all bolts are tightened to correct torque settings with Loctite. Recheck in 500km

Size	Torque (Nm)	Torque (ft-lb)
M12	85	64

1. Start with the vehicle's front and rear wheels chocked and the vehicle in gear or park, with the hand brake, applied.
2. Remove the shock absorber and shock tower as per the vehicle's service manual.
3. Carefully cut the welds off the OE bolts of the shock tower and press out.
4. Place the 50mm spacers between the coil tower and the shock tower. Then secure with the three (3) supplied M12x90mm bolts and Nylock/cone locknuts.
5. Tighten to the correct torque settings.
6. Refit the shock absorber to the vehicle as per the vehicle's service manual. Then repeat the process for the other side.



SUPERIOR ENGINEERING.COM.AU

FIGURE 1: SHOCK TOWER LIFT KIT

INSTALLATION INSTRUCTIONS