

INSTALLATION INSTRUCTIONS

PART DESCRIPTION: Nissan GQ/GU Weld-In Drop Out Cone			
PART LISTING			
ITEM#	PART#	QUANTITY	DESCRIPTION
1		2	WELD IN DROP OUT CONES

NOTES: Read and understand these installation instructions before beginning the installation process. Retain these installation instructions for future reference. It is recommended that this item is to be installed by a qualified person.

CAUTION

Make sure all fuel and brake lines are clear and out of the way of any damage. Also, remove any rubber or plastic connected to the coil tower and refit after the process is completed.

WARNING

Welders can cause serious injury and death if used incorrectly. Seek the assistance of a qualified person

1. Start with the vehicle securely on a hoist and the rear diff supported.
2. Remove the rear coils as per the vehicle's service manual.
3. Hold the coil drop out cone up under the chassis where the coil would locate, the cone will be a nice fit when in position.
4. Weld the drop out cone in place. Only 3 small 20mm welds spread evenly around the drop out cone are needed.
5. Give a light coat of paint to prevent rust.
6. Refit the rear coils as per the vehicle's service manual.



FIGURE 1: FITTED COIL DROP OUT CONE

INSTALLATION INSTRUCTIONS