

Fitting Instructions #5565IS

Ford Ranger P703 2022-On | Ford Everest U704 2022-On

Front Sway Bar D-Bush Kit



Note: This job can be done with the vehicle on the ground.

- Remove the front sway bar D-bushing brackets from both sides.
- Swing the sway bar down and away from the vehicle.
- Remove the brackets from the bushings.
- Remove the D-Bushings from the sway bar.
- Clean the sway bar surface ready for the new bushings.
- Using the supplied grease, grease the bore and faces of the new D-bushings.
- Install the new bushings onto the sway bar.
- Re-install the brackets onto the new bushings.
- Re-install the sway bar back into the vehicle.
- Torque the OE bolts down to the OE specifications.
- Wipe away any excess grease with a rag.

