



## GQ PATROL/MAVERICK BONNET STRUT FITTING INSTRUCTIONS

Thanks for your purchase & supporting small Aussie business!

1. Prop bonnet as normal.
2. Measure 25mm as shown. Drill the 8mm hole, allowing room for the nut.



3. Put the strut on bottom ball and bring it up with bracket and mark where to mount. There is enough stroke on the strut to allow the bonnet to lift higher by approx. 100mm. Use a stick etc to hold bonnet higher if you wish, then mark it. You may have to trim back the sound insulation. Mount brackets with nutserts as shown. Keep the strut as square as possible.



5. Repeat on passenger side. Make sure you put clips back on!

Cheers,

Wazza – Strut Your Stuff Gas Struts