



SAFARI R-SPEC SNORKEL

SS73R

01/04/15

ITEM	DESCRIPTION	QTY	PART NO.
1	SNORKEL BODY	1	330-133-000R
2	3" AIR RAM ASSEMBLY	1	000-135-050
6	BRACKET – UPPER MOUNTING	1	330-032-000
3	STUD - S/S – 8mm1.25 x25mm O/L	4	000-110
4	WASHER - BODY – 8mm x 30mm	4	000-311-300
5	NUT - NYLOC – 8mm1.25	4	000-205-300
7	BOLT - HEX – M6 x14mm (SEMS)	2	000-002-100
9	CLIP - BODY – PLASTIC	3	000-960
10	SCREW - S/T - 4.2 x13mm	3	000-951
11	ADAPTOR - AIR CLEANER	1	330-023-000
12	"O" RING - $\frac{5}{16}$ " SECTION x 290mm	1	000-470-029
13	POP RIVET – 4mm x 12mm	6	000-958
15	TEMPLATE	1	330-017-200
16	PLUG - PLASTIC – 70mm	1	000-959-200
17	CLAMP - HOSE - 60/80	1	000-907
18	HOSE CLAMP - SIZE 48 (BLACK)	1	000-918/B

WARNING!!

**IT IS AN INSTALLER
RESPONSIBILITY TO VERIFY
ALL COMPONENTS, AND
PARTICULARLY THE
TEMPLATE ARE CORRECT,
BEFORE STARTING ANY PART
OF THE SNORKEL
INSTALLATION.**

**(CHECK TEMPLATE AGAINST
SNORKEL BODY)**



SAFARI R-SPEC SNORKEL

SS73R

TOYOTA LANDCRUISER BJ 73

3B DIESEL (3.4L)
13BT TURBO DIESEL (3.4L)

Fitment to: Right hand side
Fitting time: Approximately 120 minutes
Special Tools: 89mm holesaw
Air hacksaw (jigsaw)
Pop rivet gun

Instructions:

1. Remove the air cleaner assembly and plastic air ducting from the engine bay. The Landcruiser badge will need to be removed from the right hand guard.
2. Tape the template in position on the vehicle (refer to the drawing) and mark all the hole positions using a felt pen. Remove the template.

3. Drill a 4mm pilot hole for each of the holes. Open out the 4 mounting holes to 16mm using a step drill. Using an 89mm holesaw, cut the main hole. The drill should be held at 90⁰ to the panel while cutting this hole. After drilling/cutting, deburr each hole to leave a clean edge.
4. Screw the stainless steel studs into the inserts in the back of the snorkel. Fasten the upper mounting bracket to the snorkel using 2, 6mm bolts and washers. Locate the snorkel on the vehicle and mark the upper mounting holes on the "A" pillar using a felt pen. Remove the snorkel and drill the mounting holes to 8mm.
5. Paint all holes to prevent rust. Insert the plastic body clips into the upper mounting holes. Position the snorkel on the vehicle and secure using appropriate hardware.
6. Slide the adaptor casting onto the snorkel snout. Sit the air cleaner assembly in position, and mark the casting location on the air cleaner body. Remove the air cleaner and casting from the car. Position the casting on the air cleaner and mark the internal hole location via the adaptor snout. Remove the adaptor casting and using an air hacksaw, cut the square hole out of the air cleaner to match the casting. Rivet the casting in position on the air cleaner and seal the joint with silicone.
7. Place a bead of silicone around the adaptor snout and refit the air cleaner assembly to the car. Blank off the original air entry to the air cleaner using the blank off plug supplied. Secure this plug with a clamp.
8. Sit the air ram on top of the snorkel and secure it using the clamp supplied.
- * A small bead of silicone may be placed around the top and front edges of the snorkel to seal it against the vehicle.

SAFARI

4X4 ENGINEERING

SS73R 3B/13BT - BJ 70/73

