

TOYOTA LANDCRUISER 200 SERIES DIFF DROP UPDATES

ARB BASH TRAY FITMENT

When fitting the Roadsafe diff drop kit in a 200 series with ARB bash trays there may be interference and will require spacing of the bash trays. SB043 was designed to be a universal bash tray spacer kit.

SB043 is to be utilized when fitting ARB bash trays on a 200 series with Roadsafe diff drop kit. When using this kit on a 200 series, the (8) SB043 spacers will need to be drilled out to 10.5mm. You will also need to source 8 x M10x1.25p X 60mm long bolts.

These spacers will need to be installed above the bash tray and tubular sub-frame of bash tray, please see figure 1, 2, 3 for reference.



FIGURE 1



FIGURE 2



FIGURE 3



STEERING RACK CLEARANCE

In some instances the main long bolt will touch the rack before being fully tight. Place an appropriately sized washer under the bolt head to reduce the available length of the bolt providing clearance.

Part Number DDLC200
Landcruiser 200 Series Diff Drop Kit
Barcode 9319478603134

Part Number SB043
Universal Bash Tray Spacer Kit
Barcode 9319478651319

Manufacturers Names used for reference purposes only.