



SAFARI R-SPEC SNORKEL

SS150R

01/04/15

ITEM	DESCRIPTION	QTY	PART NO
1	BODY – SNORKEL	1	720-133-000R
2	3" AIR RAM ASSEMBLY	1	000-135-050
3	BRACKET – UPPER MOUNTING	1	720-032-000
4	HOSE-AIR ENTRY (MOULDED)	1	720-024-000
5	STUD-S/S-8mm x 1.25mm x 25mm – O.L.	5	000-110
6	WASHER-BODY – 8mm x 30mm	5	000-311-300
7	NUT – NYLOC – 8mm x 1.25mm	5	000-205-300
8	BOLT – HEX – 6mm x 1.0mm x 12mm	1	000-001
9	WASHER – STAR – 6mm	1	000-304
10	BOLT – HEX – 6mm x 14mm	3	000-002-100
11	CLIP-BODY (PLASTIC)	4	000-960
12	SCREW – SELF TAPPER – 4.2mm x 13mm	4	000-951
13	CLAMP – 50/70	2	000-926
14	EDGING-RUBBER 300mm	1	000-953-030
15	TEMPLATE	1	720-017-000
16	WASHER-BODY - 6mm x 20mm	1	000-321
17	HOSE CLAMP - SIZE 48 (BLACK)	1	000-918/B

WARNING!!

**IT IS AN INSTALLER
RESPONSIBILITY TO VERIFY
ALL COMPONENTS, AND
PARTICULARLY THE
TEMPLATE ARE CORRECT,
BEFORE STARTING ANY PART
OF THE SNORKEL
INSTALLATION.**

**(CHECK TEMPLATE AGAINST
SNORKEL BODY)**



SAFARI R-SPEC SNORKEL

SS150R

HOLDEN RODEO 97 MODEL 2.8 TURBO DIESEL

Fitment to:	Left hand side
Fitting time:	Approximately 120 Minutes
Special Tools:	83mm Hole saw Step Drill Air Hacksaw

Instructions:

1. Remove air cleaner assembly and left front wheel arch liner.
Remove indicator lens from guard.
2. Tape Template to upper rear corner of left hand guard.
With a felt pen mark out all hole positions.
Drill a 4mm pilot hole for each hole position.
Drill main two (2) holes to 83mm using the hole saw.
Using the air hacksaw trim the remaining material to join both holes.
File and de-burr hole.
Drill the remaining five (5) mounting holes to 16mm using the step drill.
Drill the very front mounting hole to 10mm using the step drill
De-burr and paint all holes.

3. Mark out the inner guard hole position by measuring back from radiator support panel 115mm.
Then down from upper guard mounting flange 137mm.
Recheck dimensions and drill a 4mm pilot hole.
Drill to 83mm using the holesaw.
De-burr and paint hole.
4. Install mounting studs to snorkel and fit to guard.
Fit upper mounting bracket between windscreen and door sealing rubber.
Bolt bracket to snorkel and mark out four (4) mounting holes on "A" pillar.
Remove snorkel and upper mounting bracket.
Drill a 4mm pilot hole for each hole position.
Drill four (4) holes to 8mm.
De-burr and paint holes.
Insert plastic plugs and fasten upper mounting bracket to "A" pillar.
Install snorkel and fasten using necessary hardware.
5. Install rubber edging to inner guard hole.
Install moulded hose to snorkel.
Remove air entry duct from air cleaner, refit air cleaner and connect moulded hose.
Fasten hose clamps.
6. Re-fit wheel arch liner and indicator lens.
7. Install air ram and fasten.



4X4 ENGINEERING

Model No: **SS150R**

4/11/97

Description: HOLDEN RODEO

Sub Assembly: SAFARI SNORKEL

