



QUICK RELEASE ROOF BRACKETS

103749




STEP 1 GENERAL BRACKET INFO

LOAD RATINGS


(Dynamic 80kg and static 210kg)
CHECK YOU RACK LOAD CAPACITY



TOP RAIL TO FIT ACCESORIES



UNDER RAIL TO FIT OVER RACK



STEP 2

USE SPEC:

These are mounting accessory only.
They are not intended to replace a roof rack.
They are to mount a tent to a vehicle specific roof rack
and other accesories for an easy release.



103749

For more info about uses contact Us.





Lock / Unlock

STEP 3 OPERATION.

Opening and release sequence of the upper rails with or without roof tent or accesories.




CAUTION!




Always ensure latch is tight as any movement during transit can damage brackets.

To tighten, the nuts must be adjusted as per drawing.




Place rails in a safe position


Front




Rear



Right



Left





STEP 4

Use these positions to place the roof tent bracket, using the original bolts set that comes included with the tent.

TMX RR 104510 002

TMX RR 104510 002

OPERATION.

Opening and release sequence of the upper rails with or without roof tent or accesories.



19  X 4
24  X 4

TMX RR 103749 001

Spacer 103749

TMX RR 103749 001

Spacer 103749





TRAILMAX[®]



🌐 trailmax.com.au

📞 1300 885 841

📷 [trailmax_australia](https://www.instagram.com/trailmax_australia)

📘 [TrailMax](https://www.facebook.com/TrailMax)

103749