



# FRIDGE FREEZER DRAWER




Instruction Manual


# Thank you for choosing our HULK 4X4 Fridge Freezer Drawer.

Please read this manual carefully before starting the device. Keep it in a safe place for future reference. If the device is passed on to another person, this manual must be handed over to the user along with it.


The manufacturer cannot be held liable for damage resulting from improper usage or incorrect operation .




## Product refrigerator bottom mounting bracket guidelines




- 1 Fasten the bottom mounting bracket to the car using screws.



- 2 Put the refrigerator on the bottom mounting bracket.



- 3 Insert the fixing pin into the card slot, as shown in the figure.



- 4 Fasten the four screws on the left, right and front, then secure the refrigerator to the bottom mounting bracket.


## Product Feature Description

FEATURE	SPECIFICATION
<b>Maximum outlet dimension</b>	785.4 X 660.1 X 270.9mm
<b>Out of package size</b>	809.6 X 630.6 X 332.9mm
<b>Volume</b>	30.8L
<b>Refrigerating method</b>	Compressor refrigeration
<b>Refrigerant</b>	R134a/39g
<b>Foaming agent</b>	Cyclopentane
<b>Rated power</b>	55W
<b>Input voltage</b>	DC12/DC24V
<b>Rated current</b>	DC12V-8.5A/DC24V-4.2A
<b>Refrigerator temperature range setting</b>	10~22°C
<b>Ambient temperature</b>	10~43°C

## Product Feature

- 1 PU insulation layer, excellent insulation performance.
- 2 Food grade inner liner.
- 3 Built-in drawer compartment.

## Function Operation Instruction



1. Plug in the DC power cable, and the display screen automatically lights up.
2. ON/OFF Settings:
 

Press the button for 1s, then release it and the device turns on  
 Press and hold for 3s and release the button to turn off the device.
3. Set key:
  - a) Temperature setting: Press the setting key for 1s, release the setting key, and the temperature number starts to blink. Press “-” and “+” to set the parameters; Then press the set button for 1s or the stop button for more than 10s to complete the setting.
  - b) When the refrigerator is started, Bluetooth is on and you can use your mobile phone to connect to Bluetooth.
  - c) Celsius or Fahrenheit display toggle: Hold down the set button for 3s, then release the button, °C/°F begins to blink, then short press “-” to switch the temperature unit to °C/°F.
4. “+” button to set parameter +1 or function selection switch.
5. “-” button to set parameter -1 or function selection switch.
6. If the power supply is cut off or disconnected, the device will automatically shut down.

## Bluetooth App

The cooler can be controlled via Bluetooth using an APP that you can install on a compatible device, to monitor and control products within a certain distance.



Scan QR code to download APP

## Matters Need Attention

- Remove all packaging materials and carefully inspect the machine to confirm that the machine, power cord and plug are in order.
- The machine should be placed on a horizontal surface with a maximum operating Angle of 30°. To ensure proper ventilation of the machine, leave a gap of at least 100 mm around all vents. Do not place the machine near an oven, radiator, or other heat source.
- Do not allow a large amount of frost to build up on the inside of the refrigerator, as this may impair cooling. Defrost by turning off the device, allowing the frost to melt, and drying the water.
- When not in use, switch to off and unplug.
- Do not take apart or modify the refrigerator.
- Do not take apart or modify the refrigerator.

## Maintenance

- Before cleaning, please ensure that there is no electricity to avoid the risk of electric shock.
- Do not use corrosive acid, alkaline solution cleaning, so as to avoid discoloration and deterioration of plastic parts.
- Often clean the stains around the box to avoid odor.
- Do not flush directly with water to avoid failure.
- Do not store items in the device if it is not turned on.
- Do not place items in the device if the inside of the device is wet or the lid is not open.

## ⚠️ WARNING



The correct treatment of this product:

This sign indicates that the product can not be thrown into the trash can like other household garbage when it is disposed of, to prevent environmental pollution and affect the health of others, and to properly dispose of it for the sustainable use of recyclable materials and save resources

## After-sales Service

This machine is guaranteed for one year from the date of purchase.

One of the following circumstances is not covered by the warranty:

1. Damage caused by improper use, maintenance and storage of consumers;
2. Not the company's maintenance personnel or designated special maintenance personnel and the product is damaged;
3. There is no purchase invoice or the purchase invoice is inconsistent with the product;
4. Damage caused by force majeure;
5. More than the warranty period.

If you find quality problems with this product, please contact the company's after-sales service center or special maintenance service point repair, do not disassemble yourself, because of the disassembly caused by quality problems or accidents, the company will not assume any responsibility. Products not within the warranty period, the company will be charged according to the relevant provisions of the company's after-sales service maintenance.

The Company reserves the right of final interpretation of the above commitments

## DISTRIBUTED BY

Automotive Imports  
22-28 Lexton Road,  
Box Hill, Victoria,  
Australia