




FORD RANGER DC 104090

ROOF RAILS REMOVE


SHEET 2/2

- -Remove the plastic cover of the bolt using a flat screwdriver
- -Handle with care.




-Remove the original bolts using allen key

- -Remove roof rails
- -Remove the original bolts using sockets.




The rubber its bolted either end. And that they can stay. leave from middle.

Trim plastic at either end at bolted area.



-Cut the ditch cover on the marked line following the graph using oscillating multi-tool.



-After making the cuts remove the ditch cover.

