TRCRANGDD

Instructions Front Diff - Drop Kit

N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Page 1 of 5

• Raise vehicle evenly and safely support.

Never rely on a Jack only

Application - Ford Ranger PX1/2/3 - Mazda BT-50 UP UR


(Always refer complete catalogue listing)

Contents - Tail shaft spacer 25mm x1

- Flat plate LH front mount x1
- Bent plate LH front mount x1
- Welded plate RH mount x1
- Steel block LH upper mount x1
- Stepped spacer x1
- Spacer 25x16x6 PX2/3
- Spacer 25x16x14 PX1
- Spacer 25x10x10 Px1
- Bolts M8x80mm x8
- Bolts M10x110mm x2
- Bolts M10x35mm x2
- Bolt M10x40mm x1
- Bolt M12x30mm x2
- Nut M10 x4
- Washer 30x10x2.5 x5



- Start by removing all 3 splash guards.
- Un-bolt front drive shaft from transfer case.



N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Page 2 of 5



- Place stand under differential
 ready to support as you un-bolt and lower down.
 - The original RH mount will have to be removed.

Use a grinder to cut from sub-frame

4----

Refer red lines.


Supplied bolts and washers

- Bolt up supplied welded bracket using M10x110 bolts, nuts and washers.
- Re-use OE bolt with supplied washer and nut when bolting to steering rack



N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Page 3 of 5



Lower Diff down slowlyready for brackets.

PX 1 PX 2/3


 Place flat plate over studs.

Note - the very upper hole is for PX1.



N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Page 4 of 5



• Place spacer and M10 x 40mm bolt in sub-frame - as per image.

Stepped spacer suits PX2/3 25x10x10 spacer PX1


Supplied nut and washer

OE nut and bolt

Note - a spacer is required between bushing and bent plate

Spacer 25x16x6 PX2/3 Spacer 25x16x14 suits Px1

• Bolt up bent plate as per image



N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Page 5 of 5

 Bolt up upper mount with steel block, with M10x35 and M12x30mm bolts. Important - re-check all bolts after 100kms travelled

Note - remove OE locating dowel from bracket/hanger

Note - the rear M12x30mm bolts may need to be shortened, depending the vehicle.

- Screw front M10 bolts in as per image below. Loctite is a good idea for these 4 bolts.
- Bolt up front drive shaft spacer with supplied M8x110mm bolts.
 Mark shaft and yoke as per below - to make sure re-aligned correctly.
- Tighten all bolts and road-test.



Steel block

Shaft spacer



